

FIG. 1 is a block diagram of a system 100. The system 100 includes a processor 102, a memory 104, a storage device 106, a network interface 108, a user interface 110, and a power supply 112. The processor 102 is connected to the memory 104, the storage device 106, the network interface 108, the user interface 110, and the power supply 112. The memory 104 is connected to the processor 102 and the storage device 106. The storage device 106 is connected to the processor 102 and the network interface 108. The network interface 108 is connected to the processor 102 and the user interface 110. The user interface 110 is connected to the processor 102 and the power supply 112. The power supply 112 is connected to the processor 102.

FIG. 1

1/6

AUS9200008000US1




FIG. 2

2/6

AUS9200008000US1





FIG. 3 is a block diagram of a computer system 300. The system includes a Processor 302, Main Memory 304, Host/PCI Cache/Bridge 308, and an Audio Adapter 316. The Processor 302 is connected to the Main Memory 304 via a Bus 306. The Host/PCI Cache/Bridge 308 is connected to the Main Memory 304 and the Audio Adapter 316. The Audio Adapter 316 is connected to the Bus 306. The Host/PCI Cache/Bridge 308 is also connected to a LAN Adapter 310, an Expansion Bus Interface 314, a Graphics Adapter 318, and an Audio/Video Adapter 319. The Expansion Bus Interface 314 is connected to a Keyboard and Mouse Adapter 320. The Graphics Adapter 318 is connected to the Bus 306. The Audio/Video Adapter 319 is connected to the Bus 306. The LAN Adapter 310 is connected to the Bus 306. The Keyboard and Mouse Adapter 320 is connected to the Bus 306. The Bus 306 is connected to a SCSI Host Bus Adapter 312, which is connected to a Disk 326, a Tape 328, a CD-ROM 330, and a DVD 332. The Disk 326 is connected to the SCSI Host Bus Adapter 312. The Tape 328 is connected to the SCSI Host Bus Adapter 312. The CD-ROM 330 is connected to the SCSI Host Bus Adapter 312. The DVD 332 is connected to the SCSI Host Bus Adapter 312. The SCSI Host Bus Adapter 312 is connected to the Bus 306. The Bus 306 is also connected to a Modem 322 and Memory 324. The Modem 322 is connected to the Bus 306. The Memory 324 is connected to the Bus 306.

FIG. 3

3/6

AUS9200008000US1



300

FIG. 4

4/6

AUS920000800US1

400




FIG. 5

5/6

AUS920000800US1

500




FIG. 6

6/6

AUS920000800US1

600

